


EXPLODED VIEW



PARTS LIST

2007.4

◆Parts may be changed with or without notice for improvement.

PARTS No.	NAME OF PARTS	PER SET	PARTS CODE	PARTS No.	NAME OF PARTS	PER SET	PARTS CODE
1	Hammer Case	1	12CE01	23	Regulator	1	12CE23
2	Hammer Case Gasket	1	12CE02	24	Housing Cap	1	12CE24
3	Housing Bush	1	12CE03	25	Screw	4	12CE25
4	Retainer Ring	1	12CE04	26	Spring Washer	4	12CE26
5	O-Ring	1	12CE05	27	Regulator Dial	1	12CE27
6	Anvil Shank	1	12CE06	28	O-Ring	1	12CE28
7	Hammer Frame	1	12CE07	29	Reverse Valve	1	12CE29
8	Hammer	2	12CE08	30	Reverse Lever	1	12CE30
9	Hammer Pin	2	12CE09	31	Screw	1	12CE31
10	Motor Housing	1	12CE10	32	Spring	2	12CE32
11	Ball Bearing	1	12CE11	33	Steel Ball	2	12CE33
12	Front End Plate	1	12CE12	34	Spring Pin	1	12CE34
13	Spring Pin	1	12CE13	35	O-Ring	1	12CE35
14	Rotor	1	12CE14	36	Trigger	1	12CE36
15	Rotor Blade	6	12CE15	37	Valve Seat	1	12CE37
16	Cylinder	1	12CE16	38	Valve	1	12CE38
17	Spring Pin	1	12CE17	39	Valve Spring	1	12CE39
18	Rear End Plate Gasket	1	12CE18	40	O-Ring	1	12CE40
19	Rear End Plate	1	12CE19	42	Deflector	1	12CE42
20	Ball Bearing	1	12CE20	43	Deflector Gasket	1	12CE43
21	Housing Cap Gasket	1	12CE21	44	Muffler Foam	1	12CE44
22	O-Ring	1	12CE22	45	Inlet Bushing	1	12CE45