


EXPLODED VIEW



PARTS LIST

2008.10

◆Parts may be changed with or without notice for improvement.

PARTS No.	NAME OF PARTS	PER SET	PARTS CODE	PARTS No.	NAME OF PARTS	PER SET	PARTS CODE
1	Drill Chuck	1	387001	25	Reverse Button	1	387025
2	Screw	1	387002	26	Roll Pin	1	387026
3	Chuck Spacer	1	387003	27	Trigger	1	387027
4	Clamp Nut	1	387004	28	Valve Shaft	1	387028
5	Internal Gear	1	387005	29	Spring	1	387029
6	Ball Bearing	1	387006	30	O-Ring	1	387030
7	Washer	1	387007	31	Washer	1	387031
8	Planet Gear Pin	2	387008	32	O-Ring	1	387032
9	Planet Gear	5	387009	33	Needle Roller	1	387033
10	Planet Carrier	1	387010	34	Side Plate	1	387034
11	Needle Bearing	1	387011	35	Reverse Valve	1	387035
12	Ball Bearing	1	387012	36	Reverse Bush.	1	387036
13	Internal Gear	1	387013	37	Motor Housing	1	387037
14	Retaining Ring	1	387014	38	Silencer	1	387038
15	Planet Carrier	1	387015	39	Deflector	1	387039
16	Motor Pin	1	387016	40	Screw	2	387040
17	Ball Bearing	1	387017	41	Valve Seat	1	387041
18	Front End Plate	1	387018	42	Valve	1	387042
19	Cylinder	1	387019	43	Valve Spring	1	387043
20	Rotor Blade	5	387020	44	Air Inlet	1	387044
21	Rotor	1	387021	45	Chuck Key	1	387045
22	Rear End Plate	1	387022	46	Handle Kit	1	387046
23	Ball Bearing	1	387023	47	Hex. Wrench	1	387047
24	Motor Gasket	1	387024				